

Protean™ Radio Remote Control

Eight Button Radio Kit

Operation Description	Voltage Type	No. of Transmitters	Part No.	Wt lb (kg)
Normally-open, single-speed buttons, with a stop, start/auxiliary, up and down buttons. The radio is suitable for three motions (6 directions) and provides a power-on (mainline) connection. The start button also doubles as an additional auxiliary relay.	AC	1	700PR08	2.74 (1.24)
	AC	2	700PR08D	3.08 (1.40)
	DC	1	700PR08-DC	2.74 (1.24)
	DC	2	700PR08D-DC	3.08 (1.40)

Numbered Transmitter Face Plates



Each face plate shown is pre-numbered for 4, 6 or 8 button transmitters.


Description	Part No.
4-Button Face Plate	701P0045
6-Button Face Plate	701P0065
8-Button Face Plate	701P0085

Button Face Plates with Legend



The kits shown below contain either a 4, 6 or 8 button face plate with “blank” spots for legend names and one legend sheet as shown to the below.

To set up the face plate, choose the appropriate label from the legend sheet and apply it to the underside of the faceplate before applying the faceplate to the transmitter. The faceplate is clear in the open button positions allowing the label to show through.



Description	Part No.
4-Button Face Plate, with 2 blank spots	701P0219
6-Button Face Plate, with 4 blank spots	701P0220
8-Button Face Plate, with 6 blank spots	701P0221